





PRODUCT DESCRIPTION

The FPT500 is an industrial grade power supply for the 3-phase mains system, it is incorporated into a rugged wall-mount housing with an IP65 and IP67 degree of protection.

It provides two to four stabilized outputs that are galvanically separated from the input. The negative potential of the outputs is permanently connected to PE within the unit.

The most outstanding features of the FPT series are the compact size, the wide operating temperature range, the extremely low input inrush current and the very high efficiencies, which are achieved through various design technologies. Large output capacitors can absorb and store regenerative energy from breaking motors.

High immunity to transients and power surges as well as low electromagneticemissions and an international approval package makes the use in nearly every application possible.

ORDER NUMBERS

Description: Power supply FPT500

 Order Number
 Input
 Output

 FPT500.247-064-102*
 7/8"d
 1x M12-A

 2x 7/8" - 5pin

Accessories: Chapter 21
Related Products Chapter 22

*For DIN rail mounting PSU: (Order Number)D e.g. FPT500.247-064-102D

POWER SUPPLY 380-480Vac 24V 500W

- IP 65 and IP67 degree of protection
- 1000 W_{peak} 5 s
- 3AC 380-480 V wide-range input
- 1 NEC Class II output
- 2 switchable outputs
- · Outputs for actors and sensors shares one channel
- 95.6 % full load and excellent partial load efficiencies
- DIN rail mounting possible, option "D"
- Output connected to PE (PELV)
- Version without connection to PE on request
- Large output capacitors
- Not potted
- Negligible low input inrush current surge
- Full power between -25 °C and +55 °C
- IO-Link
- 3 year warranty

SHORT-FORM DATA

Output voltage DC 24 V Nominal Adjustment range 24-28 V Factory setting 24.5 V

Output power Continuous: Up to:

600 / 500 / 350 W +45 °C / +55 °C / +70 °C

Short term up to 5 s

1000 / 700 W +55 °C / +70 °C

Derate linearly +45 °C to +70 °C

Number of output 3

Output currents 1 NEC Class II

2 Settable per output; up to 10 A

Input voltage 3AC 380-480 V ±15 %

 $\begin{array}{lll} \mbox{Power factor} & 0.94 \, / \, 0.95 & \mbox{At } 3x400 \, / \, 480 \, \mbox{Vac} \\ \mbox{AC Inrush current} & 1.9 \, / \, 1.8 \, \mbox{A}_{\rm peak} & \mbox{At } 3x400 \, / \, 480 \, \mbox{Vac} \end{array}$

Efficiency 95.8 / 95.6 % At 3x400 / 480 Vac

Losses 22 / 23 W At 3x400 / 480 Vac

Hold-up time 24 / 24 ms At 3x400 / 480 Vac

Temperature -25 °C to +70 °C

range

Size (wxhxd) 181x183x59 mm Without connectors

Weight 1200 g / 2.7 lb

MAIN APPROVALS

For details and the complete approval list, see chapter 19.

CB Report



IEC 62368-1 IEC 61010-2-201





INDEX

1.	Intended Use	4
2.	Installation Instructions	4
3.	AC-Input	5
4.	DC-Input	
5.	Input Inrush Current	6
6.	Output	7
7.	Hold-up Time	9
8.	IO-Link Interface	10
9.	Efficiency and Power Losses	16
10.	Lifetime Expectancy	17
11.	MTBF	17
12.	Functional Diagram	18
13.	Dimensions and Connector Variants	
14.	User Interface	20
15.	EMC	23
16.	Environment	25
17.	Safety and Protection Features	
18.	Dielectric Strength	27

19.	Appr	oved, Fulfilled or Tested Standards	28			
20.	Regulatory Product Compliance					
21.	Acce	ssories	29			
21	.1.	DIN RAIL Mounting KIT: ZM.FPDRA-11	29			
21	.2.	Mounting Braket: ZM.FPMBA-11	29			
21	.3.	Connectors	30			
22.	Relat	ted Products	31			
23.	Appl	ication Notes	32			
23	.1.	Repetitive Pulse Loading	32			
23	.2.	External Input Protection	32			
23	.3.	Two Phases Operation				
23	.4.	Inductive and Capacitive Loads	32			
23	.5.	Back Feeding Loads	33			
23	.6.	Mounting Orientations	33			
24.	IO-Li	nk Data Types and Description	34			
24	.1.	Cyclic Data	34			
24	.2.	Acyclic data	36			
24	.3.	Events	42			

The information given in this document is correct to the best of our knowledge and experience at the time of publication. If not expressly agreed otherwise, this information does not represent a warranty in the legal sense of the word. As the state of our knowledge and experience is constantly changing, the information in this data sheet is subject to revision. We therefore kindly ask you to always use the latest issue of this document (available under www.pulspower.com).

No part of this document may be reproduced or utilized in any form without our prior permission in writing.

Packaging and packaging aids can and should always be recycled. The product itself may not be disposed of as domestic refuse.

TERMINOLOGY AND ABREVIATIONS


PE and 🖶 Symbol	PE is the abbreviation for Protective Earth and has the same meaning as the symbol $igoplus$.
Earth, Ground	This document uses the term "earth" which is the same as the U.S. term "ground".
T.b.d.	To be defined, value or description will follow later.
3AC 400 V	A figure displayed with the AC or DC before the value represents a nominal voltage with tolerances (usually $\pm 15\%$) included.
	E.g.: DC 12 V describes a 12 V battery disregarding whether it is full (13.7 V) or flat (10 V)
3x 400 Vac	A figure with the unit (Vac) at the end is a momentary figure without any additional tolerances included.
50 Hz vs. 60 Hz	As long as not otherwise stated, 3AC 400 V parameters are valid at 50 Hz mains frequency.
may	A key word indicating flexibility of choice with no implied preference.
shall	A key word indicating a mandatory requirement.
should	A key word indicating flexibility of choice with a strongly preferred implementation.
Us	Sensor output
Ua	Actor output





NOMENCLATURE

Detail	Description
FPT	380-480 V 3 Phase IP54-67 Power Supply
FPS	100-240 V 1 Phase IP54-67 Power Supply
FPH	200-240 V 1 Phase IP54-67 Power Supply Highline Input Voltage
300	300 W Power Class
500	500 W Power Class
241 / 481	Standard Power Supply with Output Voltage 24-28 V / 48-52 V Setting and LED Bar
242 / 482	Basic Power Supply without Voltage Setting and LED-Bar. This version has a status LED Bar.
245 / 485	Power Supply with up to 4 E-Fuse Channels
246 / 486	Power Supply with up to 4 NEC Class II Channels
247 / 487	Power Supply with NEC Class II and E-Fuse Channel
0xx	Terminal configuration e.g002. Input: HanQ4/2 Com: M12-A Output: HanQ4/0
1xx	Consecutively numbered







1. Intended Use

This device is designed for indoor use and is intended for commercial applications, such as in industrial control, process control, monitoring and measurement equipment.

Do not use this device in equipment where malfunction may cause severe personal injury or threaten human life. If this device is used in a manner outside of its specification, the protection provided by the device may be impaired.

2. Installation Instructions

▲ DANGER

Risk of electrical shock, fire, personal injury or death.

- Turn power off before working on the device. Protect against inadvertent re-powering.
- Do not open, modify or repair the device.
- Do not touch during power-on and immediately after power-off. Hot surfaces may cause burns.
- Install the device on a large enough flat surface. Sharp edges on the back may cause injury.
- If damages or malfunctioning occur during installation or operation, immediately turn power off and send unit to the factory for inspection.
- The device is designed as "Class of Protection I" equipment according to IEC 61140. Do not use without a proper PE (Protective Earth) connection.

▲ WARNING

Risk of damages on the device

- Keep the following minimum installation clearances: 50 mm on top and bottom, 10 mm on the front and 10 mm left and right side.
- The maximum surrounding air temperature is +70 °C (+158 °F). The operational temperature is the same as the ambient or surrounding air temperature and is defined 2 cm below the device.
- The device is designed to operate in areas between 5 % and 95 % relative humidity.
- Clean only with a damp cloth.

Obey the following installation instructions:

This device may only be installed and put into operation by qualified personnel. This device does not contain serviceable parts. The tripping of an internal fuse is caused by an internal defect. Install the device onto a flat surface with the terminals on the bottom of the device. Other mounting orientations require a reduction in output power, chapter 23.6.

For wall mounting use 4 screws. Two on top and 2 on bottom mounting holes. Recommended screw size is M4 (UNC 8-32). The enclosure of the device provides a degree of protection of IP65 and IP67 when installed with all mating connectors firmly connected. The device is designed for pollution degree 3 areas in controlled environments.

Assure that during installation no moisture or dirt gets into the connections. Operation in areas where moisture or condensation can be expected is possible.

The negative potential of the outputs is permanently connected to PE within the unit. Do not connect the negative potential of any output to PE outside the unit.

For TN,TT mains systems with earthed neutral and IT star mains systems with insulation monitoring the device is designed for overvoltage category III zones up to 2000 m (6560 ft) and for overvoltage category II zones up to 5000 m (16400 ft).

For TN, TT, IT delta mains systems or IT star mains systems without insulation monitoring the device is intended for overvoltage category II zones up to 2000 m (6560 ft). The device is designed to be safe in case of a single phase loss and does not require an external protection. Functionality is limited see chapter 23.3.

The device is designed for altitudes up to 5000 m (16400 ft). Above 2000 m (6560 ft) a reduction in output current is required and the operation is limited according mains systems described above. The device is designed, tested and approved for branch circuits up to 20 A (UL) and 32 A (IEC) without additional protection device. If an external fuse is utilized, do not use circuit breakers smaller than 6 A B- or C-characteristic to avoid a nuisance trip. A disconnecting means shall be provided for the input of the device. This must be suitably located and easily accessible. The disconnecting means must be marked as the such for the device.





3. AC-Input

The device is suitable to be supplied from TN, TT or IT mains networks. For more details, please review chapter 2.

AC input voltage rated range Nom. 3AC 380-480 V AC input operating range 3x 323-552 Vac

Input frequency Nom. 50–60 Hz ±6 %

Turn-on voltage Typ. 3x 320 Vac Steady-state value, see Fig. 3-1 Shut-down voltage Typ. 3x 300 Vac Steady-state value, see Fig. 3-1

Loss of one phase will continue to operate without interruption if loaded below limits in figure see Fig.

23-1

External input protection See recommendations in chapter 2 .

		3AC 400 V	3AC 480 V	
Input current	typ.	0.8 A	0.66 A	At 500 W, symmetrical phase voltages, see Fig. 3-3 Power
Power factor	typ.	0.94	0.95	At 500 W, see Fig. 3-4
Start-up delay Rise time	typ. typ. typ.	2 s 10 ms 12 ms	2 s 10 ms 12 ms	At 500 W symmetrical phase voltages, see Fig. 3-2 At 500 W constant current load, 0mF load, see Fig. 3-2 At 500 W constant current load, 12.5mF, see Fig. 3-2
Turn-on overshoot	Max.	500 mV	500 mV	See Fig. 3-2




Fig. 3-1: Input voltage range




Fig. 3-2: Turn-on behavior, definitions




Fig. 3-3: Input current vs. output power at 24 V output voltage




Fig. 3-4: Power factor vs. output power at 24 V output voltage





DC-Input 4.

Do not operate this power supply with DC-input voltage.

Input Inrush Current 5.

The power supply is equipped with an active inrush current limitation circuit, which limits the input inrush current after turn-on to an extremely low value. The inrush current is usually smaller than the steady state input current.

3AC 400 V 3AC 480 V

Inrush current *)	max.	2.1 A _{peak}	2 A _{peak}	Temperature independent
	typ.	1.9 A _{peak}	1.8 A _{peak}	Temperature independent

*) The charging current into EMI suppression capacitors is disregarded in the first microseconds after switch-on.




Fig. 5-1: Typical turn-on behavior at nominal load and 25°C ambient temperature





6. Output

The outputs provide a (PELV/ES1) rated voltage, which is galvanically isolated from the input voltage. The negative potential of the outputs is permanently connected to PE within the unit. Do not connect any output to PE (Ground).

The device is designed to supply any kind of loads, including capacitive and inductive loads. If capacitors with a capacitance >20mF are connected to one output, this output might switch off after turning the unit or the output on or connecting the load.

All outputs are individually current limited. In case of an overload, the individual output switches off and needs to be reset manually with the reset button on the front of the device or via IO-Link. A cycling of the input power does not reset the output. The failure signals are stored until a reset is intentionally initiated.

For protection reasons a delay of at least 5 seconds is mandatory, before an output can be reset after it has been switched off. Otherwise the green LED will flicker after pushing the button. The unit is shipped with all outputs turned on. The ON/OFF function has no safety feature included.

The sum of the configured output power of all outputs may exceed the total output power of available power budget, see Fig. 6-2. If this is the case, the output with the highest number will tripped first followed by the next output to ensure that the lower channel number will supply continuous power and see no voltage dips.

Outputs start sequentially from 1 to 4 with an interval of 150ms, see Fig. 6-1.

Number of outputs Output voltage	Nom.	3 24 V	Fact	ory setting 24.5 V			
Adjustment range		24-28 V		Adjustable in steps: 24 V, 24.5 V, 25 V, 25.5 V, 26 V, 26.5 V, 27 V and 28 V			
Factory setting	Тур.	24.5 V	±0.2	%, at nominal load	d		
Line regulation	Max.	10 mV	Betv	ween 3x323 and 552	Vac input voltage ch	ange	
Load regulation	Тур.	100 mV	Betv	ween 0 and 600 W o	output load, static valu	c value	
Ripple and noise voltage	Max.	100 mVpp	Ban	dwidth 20 Hz to 20	MHz, 50 Ohm		
Output current	Order nu FPT500.2	umber C 47-064-102	Outputs 1 2	Connector 1x M12-A 2 x 7/8" 5pin	Max. current NEC Class II 10 A each output	Picture Fig. 6-4 Fig. 6-3	
Total output power short term up to 5s	Nom. Nom. Nom.	600 W 500 W 350 W 1000 W	outp At + At +	outs. 55°C at ambient tei 70°C at ambient tei to +55°C at ambie	ent temperatures, fo mperatures, for the su mperatures, for the su ent temperatures, fo	ım of all outputs. ım of all outputs.	
	Nom. Derate li	700 W At +70 °C at ambient temperatures, for the sum of all output linearly between +45 °C and +70 °				ım of all outputs.	
Overload behavior		Trip curve	See	Fig. 6-3			
Output capacitance	Тур.	12 500 μF	Inclu	uded inside the pow	er supply, common fo	r all four outputs	
Parallel Use			Do r	not parallel units for	r higher output curre	nts	
Back-feeding loads	Max.	35 V / 4 J	load mat			ply. It does not	






Fig. 6-1: Sequential start of the outputs




Fig. 6-2: Tripping of the channel with the lowest priority when the power budget is exceeded




Fig. 6-3: Trip curve diagram




Fig. 6-4: Trip curve diagram for NEC Class II





7. Hold-up Time

The hold-up time is the time during which a power supply's output voltage remains within specification following the loss of input power. The hold-up time is output load dependent. At no load, the hold-up time can be up to several seconds. The status LED is also on during this time.

		3AC 400 V	3AC 480 V	
Hold-up Time	typ.	56 ms	56 ms	At 250 W output load, see Fig. 7-1
	min.	47 ms	47 ms	At 250 W output load, see Fig. 7-1
	typ.	24 ms	24 ms	At 500 W output load, see Fig. 7-1
	min.	20 ms	20 ms	At 500 W output load, see Fig. 7-1




Fig. 7-1: Hold-up time vs. input voltage




Fig. 7-2: Shut-down behavior, definitions





8. IO-Link Interface

The IO-Link interface used in this power supply is compliant to IO-Link protocol V1.1 and can be connected to any IO-Link masters compliant to V1.1 of the IO-Link protocol. This allows a transparent data flow to the sensors and actuators and therefore more transparent and easier way to monitor the current status of the power supply.

In case of no or defective connectivity of the IO-Link, the power supply can also be operated on smoothly. Due to a built-in EEPROM, previously inputted data will be drawn from its storage.

To operate the IO-Link interface it is required to install/upload the IODD-File (IO-Link Device Description) into the connected IO-Link master. The most recent IODD file can be found on the PULS website (www.pulspower.com) in the download section of the individual product page. The device can also be accessed via IO-Link, if the power supply is not connected to AC-mains and in a switched off mode.

IO-Link Version	V1.1	To get full performance, it is recommended to use IO-Link
IO-Link master Version	V1.1	
Baud-Rate	COM3 (230.4 kBaud)	
Cycle Time	2ms	Cycle time refers to the reloading speed of certain process data
SIO-Mode	yes	Class B
Process Data Length	13 bytes	

The power supply provides three categories of data via IO-Link. They are divided between read only or read- and customizable data.

Control Settings

This set of data is customizable. The data in control settings can be adjusted to the user's preference to ensure an even better operation of the power supply. Typical control settings are e.g. setting tripping points, setting per-alarm levels, etc.

Parameter write Output Voltage Setpoint	Value range 24.0-28.0 V	Description Output Voltage Setpoint Pre-Setting- 24.5 V
Standby	0 - unit is operating 1 - unit in standby	PSU can be switched into standby, where all outputs turn off. Pre-Setting- 0=unit is operating
Configuration Setting	0 - human-machine interface only 1 - IO-Link only 2 - both 3 - none (button lock)	Controls the configurability of the PSU, which can be restricted to local HMI or IO-Link only. Configuration can also be blocked completely. Pre-Setting- 2=both
E-Fuse Channel on/off	0 – off 1 - on	Used to control the state of output channel switches (ON/OFF) or to reconnect a tripped channels. Bit coded parameter. Pre-Setting- 1=ON for all channels
E-Fuse trip value channel 1 to channel 4	1-10/12 A	Defines the output current threshold for each E-Fuse channel, where the electronic fuse is triggered. Pre-Setting- 10/12 A (depends on type of output connector)
E-Fuse Pre-alarm level channel 1 to channel 4	10-100 %	Defines the threshold for the event "Output current pre-alarm for each channel". Pre-Setting- 80 %
PSU total output current Pre-alarm level	1-100 A	Defines the threshold for the event "PSU output current pre-alarm". To suppress event generation, set this value to max (100 A). Pre-Setting- 20A

All parameters are specified at 24 V, 20 A, 400 Vac, +25 °C ambient and after a 5 minutes run-in time unless otherwise noted.

10 / 42





Parameter

The parameter values can be accessed to read out additional data (e.g. current output voltage, temperatures etc

Parameter read	read out value range	Description
Output Voltage Setpoint	24.0-28.0 V	Output Voltage Setpoint Pre-Setting- 24.5 V
Standby	0 - unit is operating 1 - unit in standby	PSU can be switched into standby, where all outputs turn off. Pre-Setting- 0=unit is operating
Configuration Setting	0 - human-machine interface only 1 - IO-Link only 2 - both 3 - none (button lock)	Controls the configurability of the PSU, which can be restricted to local HMI or IO-Link only. Configuration can also be blocked completely. Pre-Setting- 2=both
E-Fuse Channel on/off	0 - off	Used to control the state of output channel switches
	1 - on	(ON/OFF) or to reconnect a tripped channels. Bit coded parameter. Pre-Setting- 1=ON for all channels
E-Fuse trip value channel 1 to channel 4	1-10/12 A	Defines the output current threshold for each E-Fuse channel, where the electronic fuse is triggered. Pre-Setting- 10/12 A (depends on type of output connector)
E-Fuse Pre-alarm level channel 1 to channel 4	10-100 %	Defines the threshold for the event "Output current pre-alarm for each channel". Pre-Setting- 80 %
PSU total output current Pre-alarm level	1-100 A	Defines the threshold for the event "PSU output current pre-alarm". To suppress event generation, set this value to max (100 A). Pre-Setting- 20 A
EEPROM Status	0 - OK 1 - Recoverable error detected 2 - Unrecoverable error	PSU internal EEPROM status information. If unrecoverable error is detected, the PSU may operate with pre-setting values.
PSU events	bit 0 - DC-OK bit 1 - DC-Warning bit 2 - Bonus Power bit 3 - Over Temperature CAP bit 4 - Over Temperature PSU bit 5 - Over load bit 6 - High voltage input bit 7 - Low voltage input bit 8 - Power supply down bit 9 - Predictive maintenance power supply bit 10 - 2 phase operation bit 12 - PSU settings changed via HMI bit 13 - PSU hardware failure	Collection of active events of the PSU. Bit-coded parameter, bits 11,14-15 not used.
Temperature secondary inside	-40-150 °C	Temperature at secondary DC output area inside PSU
Max. temperature secondary inside	-40-150 °C	Maximum temperature at secondary DC output area inside PSU
Temperature primary inside	-40-150 °C	Temperature at primary AC input area inside PSU
Max. temperature primary inside	-40-150 °C	Maximum temperature at primary AC input area inside PSU
AC Input Voltage RMS		Actual Input Voltage RMS (phase-phase)





Parameter read	read out value range	Description
Actual output voltage	0-49 V	Actual average output voltage
Actual output current	0-68 A	Actual average total output current
E-Fuse current channel 4	0-15 A	Actual average E-Fuse output current for each E-Fuse channel
E-Fuse output status	bit 0 - Ch1 bit 1 - Ch2 bit 2 - Ch3 bit 3 - Ch4 0 - off 1 - on	Actual state of E-Fuse output channels Bit coded parameter. 0 - channel is off 1 - channel is on
E-Fuse trip status channel 1 to channel 4	 0 - No trip 1 - Over-load trip 2 - Short circuit trip 3 - Temperature trip 4 - Power budget trip 5 - Installation failure trip 6 - Sensor fault trip 7 - Fatal fault trip 	Actual trip state of E-Fuse channel If the E-Fuse has tripped, this parameter gives detailed information about the reason. This information might help for failure analysis in the application.
Stress level	0 - "<5 %" 1 - ">5 %" 2 - ">25 %" 3 - ">50 %" 4 - ">75 %"	Stress level based on output power delivery. This parameter gives an indication about the total power consumption of the application and the remaining margin.
Remaining Endurance LED coded	0 - "<10 %" 1 - ">10 %" 2 - ">25 %" 3 - ">50 %" 4 - ">75 %"	This parameter gives an estimated remaining endurcance indication. Overall performance of the PSU might decrease at low remaining endurance code.
Remaining Endurance	10-99 %	This parameter gives an estimated remaining endurcance indication in percent. Overall performance of the PSU might decrease at low remaining endurance.





Counter

E-Fuse Number of Startups 0-150000 Counts the number of startups on each E-Fuse channel 1 to channel 4 channel over the whole lifetime. E-Fuse Number of Overcurrents 0-150000 Number of Overcurrents on each E-Fuse channel over channel 1 to channel 4 the whole lifetime. Operating time 0-1000000 Total operating hours hours 0-59 operating minutes minutes Transient VDE-0160 Counter 0-150000 Transient Counter overall overall Transient VDE-0160 Counter 0-65535 **Transient Counter last 2 minutes** last 2 minutes Turn-on Counter 0-150000 Turn-on Counter of the PSU Uptime since last turn-on 0-1000000 Uptime since last turn-on - hours hours Uptime since last turn-on - minutes minutes 0-59

Device Status

Item [5]

Device Status	0 - Device is operating properly1 - Maintenance-Required2 - Out-of-Specification3 - Functional-Check4 - Failure	Overall PSU device state
Detailed Device Status Item [1] Item [2] Item [3] Item [4]	Octet Strings	Shows up to 5 pending events 3 octets per subindex- Octet 1 – EventQualifier Octet 2,3 - EventCode





Event Data

This set of data is on read only. Event data reports on parameter errors and warns of device failures of the power supply to the IO-Link master. It is triggered when certain critical conditions or control settings are exceeded. Typical events are e.g. ambient temperature too hot, high input voltage, etc.

Events Parameter error – Check data sheet and values	Event-type Error	Description
Device temperature over-run – Clear source of heat	Warning	
Events. DC-Warning	Warning	Output voltage dips more than 10% below adjusted output voltage
Events. Bonus Power	Notification	Output current is 5% more than maximum for more than 3s
Events. Over Load	Warning	Load higher than allowed
Events. High Voltage Input	Warning	Input to high
Events. Low Voltage Input	Warning	Input to low
Events. Power Supply down	Warning	No link from IO-Link Transceiver to Power Supply
Events. Predictive Maintenance Power Supply	Warning	The estimated remaining lifetime has reached 10%. Performance of PSU might be limited due to aging effects of components.
Events. Two phase AC supply	Warning	One leg of the 3-phase system is missing
Events. PSU setting changed via HMI	Warning	A PSU setting was changed via man-machine interface.
Events. PSU hardware failure	Warning	Critical PSU hardware failure detected. PSU shut down.
Events. PSU output current Pre-alarm	Warning	Total PSU output current exceeds pre-alarm limit
Events. E-Fuse channel 1 to channel 4 Tripped	Warning	For each E-Fuse channel when is tripped due to overcurrent
Events. Output current Pre-alarm channel 1 to channel 4	Notification	For each E-Fuse channel when Output current exceeds pre-alarm limit





Process Data

This set of data is on read only. Process data reports on the current state and conditions of the power supply to the IO-Link master. Typical process data are, e.g. actual output voltage of each output channel, internal temperatures, tripping status reports, etc.

Process Actual Output total Current	Value range A	Description
Actual Output Voltage	V	Actual Output Voltage
E-Fuse Current	Α	Actual Output Current from each E-Fuse
channel 1 to channel 4		Channel
E-Fuse channel states		Actual state of E-Fuse outputs (on/off)
E-Fuse overload trip states		Overload trip state of E-Fuse outputs (ok/tripped)
E-Fuse short circuit states		Short circuit trip state of E-Fuse outputs (ok/tripped)

For a full list of data set, see chapter 24, IO-Link Data Typs and Description.





9. Efficiency and Power Losses

		3AC 400 V	3AC 480 V	
Efficiency	typ.	95.8 %	95.6%	At 24 V, 500 W
Average efficiency	typ.	94.2 %	94 %	25 % at 120 W, 25 % at 250 W, 25 % at 370 W 25 % at 500 W
Power losses	typ. typ. typ.	2.5 W 12 W 22 W	2.5 W 13 W 23 W	At 24 V, 0 W (no load) At 24 V, 250 W (half load) At 24 V, 500 W (full load)

*) The average efficiency is an assumption for a typical application where the power supply is loaded with 25% of the nominal load for 25% of the time, 50% of the nominal load for another 25% of the time, 75% of the nominal load for another 25% of the time and with 100% of the nominal load for the rest of the time.




Fig. 9-1: Efficiency vs. output power at 24 V, typ.



Fig. 9-2: Losses vs. output power at 24 V, typ.




Fig. 9-3: Efficiency vs. input voltage at 24 V, 500 W, typ.




Fig. 9-4: Losses vs. input voltage at 24 V, 500 W, typ.





10. Lifetime Expectancy

The Lifetime expectancy shown in the table indicates the minimum operating hours (service life) and is determined by the lifetime expectancy of the built-in electrolytic capacitors. Lifetime expectancy is specified in operational hours and is calculated according to the capacitor's manufacturer specification.

The manufacturer of the electrolytic capacitors only guarantees a maximum life of up to 15 years (131 400 h). Any number exceeding this value is a calculated theoretical lifetime which can be used to compare devices.

	3AC 400 V	3AC 480 V	
Calculated lifetime expectancy	43 000 h	37 000 h	At 24 V, 500 W and 40 °C
	177 000 h	168 000 h	At 24 V, 250 W and 40 °C
	135 000 h	119 000 h	At 24 V, 500 W and 25 °C
	466 000 h	476 000 h	At 24 V, 250 W and 25 °C

11. MTBF

MTBF stands for Mean Time Between Failure, which is calculated according to statistical device failures, and indicates reliability of a device. It is the statistical representation of the likelihood of a unit to fail and does not necessarily represent the life of a product.

A MTBF figure of e.g. 1 000 000 h means that statistically one unit will fail every 100 hours if 10 000 units are installed in the field. However, it can not be determined if the failed unit has been running for 50 000 h or only for 100 h.

For these types of units the MTTF (Mean Time To Failure) value is the same value as the MTBF value.

	3AC 400 V	3AC 480 V	
MTBF SN 29500, IEC 61709	253 000 h	233 000 h	At 24 V, 500 W and 40 °C
	461 000 h	427 000 h	At 24 V, 500 W and 25 °C
MTBF MIL HDBK 217F	98 000 h	93 000 h	At 24 V, 500 W and 40 °C; Ground Benign GB40
	144 000 h	138 000 h	At 24 V, 500 W and 25 °C; Ground Benign GB25
	25 000 h	24 000 h	At 24 V, 500 W and 40 °C; Ground Fixed GF40
	33 000 h	32 000 h	At 24 V, 500 W and 25 °C; Ground Fixed GF25





12. Functional Diagram





Fig. 12-1: Functional Diagram





13. Dimensions and Connector Variants



Width 181mm / 7.17" Height 183mm / 7.2" Depth 59mm / 2.32" Weight 1200g / 2.7lb Housing body material Housing cover material Installation clearances Mating connectors Aluminium alloy Hi-grade polycarbonate See chapter 2 See chapter 21.3

Input connector on power supply (X1):



Turck 7/8"d Male Pin 1: L1 Pin 2: L2 Pin 3: L3

Pin 4: PE connection

IO-Link connector on power supply (X2):



M12-A Male Pin 1: 24 Vdc supply voltage

Pin 2: n.c.

Pin 3: GND Supply voltage

Pin 4: Data IN/OUT

Pin 5: n.c.

Output connector on power supply (X3):



M12-A 5 pin Female

Pin 1: 24 Vdc (Out 1) Us

Pin 2: GND (Out 1) Ua

Pin 3: GND (Out 1) Us

Pin 4: 24 Vdc (Out 1) Ua

Actor output

Actor output

Actor output

Pin 5: FE

Output connector on power supply (X4 and X5):

7/8" 5 pin Female



Pin 1: GND (Out 2 | 3) Ua Actor output
Pin 2: GND (Out 2 | 3) Us Sensor output

Pin 3: FE

Pin 4: 24 Vdc (Out 2 | 3) Us Sensor output Pin 5: 24 Vdc (Out 2 | 3) Ua Actor output





14. User Interface



X1	Input Connector
X2	IO-Link Connector
X3, X4, X5	Output Connectors
Α	LED Bar
В	Status LED
C	Set Mode and Up and Down Button
D	Output channel LEDs & output channel ON / OFF button

Overview

LED Bar (E)

The LED Bar is a multifunctional displaying tool. The main function is to monitor the sum of all outputs (percentages scale). It also can display the output voltage (voltage scale) and output current (ampere scale) for the individual outputs. The integrated Status LED displays different running conditions of the PSU in real-time.

Output Level Controls (F)

The Output Level Controls consist of the Set Mode button and the UP/DOWN buttons. The Set Mode is used to change into tripping current settings. The UP/DOWN are used to adjust different output levels or change into the Output Current Mode.

Output Controls (G)

The Output Controls consist of an output LED and an Output ON/OFF button (ON/OFF) for each output. The Output LED displays different running conditions for output in real-time. The ON/OFF is used to switch the output on/off.

Operation Settings

Monitor Output Power Mode

The Output Power Mode displays the actual total output power after startup. It is the default mode of the LED Bar. The output Power is Displayed in percentages of 500 W. E.g. If the LED Bar is powered up till 50 %, 250 W is expended. If the LED Bar rises above 100% and therefore exceeds 500 W the 125 %-LED flashes orange. Refer to the percentage scale on the left sidebar.

Monitor Output Current Mode

The Output Current Mode is to check the output current of the individual outputs.

To inspect these output currents:

- Press the UP or DOWN button. OUT1 in the LED bar lights up in orange. The output current is displayed in real-time
 in the LED Bar below. Refer to the ampere scale on the right sidebar.
- In the LED Bar switch between the OUT1 OUT4 using the UP/DOWN buttons to check the different output current values
- Return to the Output Power Mode/default mode by pushing beyond the highest (OUT4) or lowest (OUT1) output number.





Set Tripping Current

To set a new tripping current:

- Press Set Mode for 3 s. After all LEDs light up once, the LED now displays the set voltage.
- Press Set Mode to select the right output to change the tripping current. The orange LED will indicate which output
 is selected.
- Push UP/DOWN to increase or decrease the set point. Refer to the current scale on the right sidebar. (e.g. 20 %-LED indicates 3 A).
- New point is set.
- After 15 s of non-action, the PSU will automatically switch to Output Power Mode.

Set Output Voltage

To set a new output voltage:

- Press Set Mode for 3 s. After all LEDs light up once, the LED now displays the set voltage.
- Push UP/DOWN to increase or decrease the set point. Refer to the current scale on the right sidebar. (e.g. 20 %-LED indicates 24.5 V).
- New point is set.
- After 15 s of non-action, the PSU will automatically switch to Output Power Mode.

Set Button Lock

To activate/deactivate the button lock:

 Press the UP and DOWN buttons simultaneously for 3 s. The LED bar will flash for 5 s to indicate the changed button lock status.

Reset Output


In a failure mode where the output did/didn't switched OFF:

Push and hold ON/OFF for more than 1s.

LED Signaling

Status LED (D)

The Status LED displays different running conditions of the PSU in real-time.



Green: On

DC voltage is above 90 % of set point voltage. All outputs are operating according to their settings.

OFF

DC voltage is below 90 % of set point voltage or an output channel has tripped or PSU is not powered.

Red: AC input failure

AC input drops below the specified levels and outputs turned off.

Flashes orange: Hiccup_{Plus} mode!

Output is OFF during these 18s.

Flashes red: Overtemperature

The PSU turns OFF to prevent overheating. Normal operating range continues

after the Status LED turns to solid green again.





Channel LED Signaling Overview


Below is an overview of the output LED signaling.



Fig. 14-1: Location of outputs LEDs

OFF

Output is switched OFF by ON/OFF or PSU is not powered (s. Status LED).



Output is switched on by ON/OFF.

Flashes green: Power budget tripped (slow rate: 250 ms ON / 250 ms OFF) Low priority outputs are tripped. Sum of output currents are above PSU power

budget.

Flashes green: Buttons Locked (fast rate: 125 ms ON / 125 ms OFF)
No action is carried out. Button lock feature activated. Unlock buttons by following Operation Settings > Set Button Lock. Other reason: MOSFET protection MOSFET is >90 °C or Interval between Charge Up/ Turn On cycles <5 s.

Orange: Pre-Alarm!

Output is still running. Current is above pre-alarm level and close to overload.

Flashes orange: Overload! (slow rate: 500 ms ON / 500 ms OFF)
Output is tripped. Output current is overloaded. Restart by pushing the ON/OFF.

Flashes orange: Faulty Installation (medium rate: 250 ms ON / 250 ms OFF) Output is turned OFF automatically. Cable or connected hardware on the outputs are not installed correctly. Switch OFF the output manually by pushing the specific output ON/OFF button.

- PSU with NEC Class II outputs: Difference between positive and negative/Input-Output current of the output are >1 A for 6-6.5 s
- PSU without NEC Class II outputs: Connector negative wire overcurrent according to negative trip curve, or output was contributing to negative overcurrent of another output (Ipos – Ineg > threshold), or High PE current (>12 A) was detected based on overall output current sum.

Flashes orange: Short Circuit (fast rate: 125 ms ON / 125 ms OFF)

Output is tripped. The Output's output current exceeded approx. 48A. Short circuit reasons may be electrical short, loads beyond specification, plugging-in a large capacitance during operation, etc. After pushing of specific output ON/OFF button, e-fuse output tries to turn ON.

Flashes Orange/Green: Overtemperature! (slow rate, 250 ms orange / 250 ms)

Output will automatically turned OFF when MOSFET overtemperature (125 °C) is reached. When MOSFET temperature falls below 90 °C the output will turn on automatically.

Red: Fatal MOSFET Malfunction!

PSU turns OFF. Power switch on specific output is damaged. Replacement of PSU might be required.

Possible malfunction:

Positive current output in OFF state exceeds >2 A for more than >0.5 s

Flashes red: Hardware Specs Out of Range! (slow rate, 500 ms ON / 500 ms OFF)

Affected output channel turns OFF. Measurement Circuit Hardware is out of specified range. Replacement of PSU might be required.

Possible malfunction:

- Deviations of internal output current sensors exceed acceptable
- Temperature sensor measurement out of range (-40 °C or +150 °C) for more than 5 s





15. EMC

The EMC behavior of the device is designed for applications in industrial environment as well as in residential, commercial and light industry environments.

The device is investigated according to EN 61000-6-1, EN 61000-6-2, EN 61000-6-3, EN 61000-6-4, EN 61000-3-2 and EN 61000-3-3.

EMC immunity Electrostatic discharge Air discharge	EN 61000-4-2	Contact discharge Air discharge	8 kV* 15 kV*	Criterion A Criterion A
Electromagnetic RF field	EN 61000-4-3	80 MHz - 2.7 GHz 2.7 GHz – 6 GHz	15 V/m* 10 V/m	Criterion A Criterion A
Magnetic field	EN 61000-4-8	50 Hz/60 Hz	30 A/m	Criterion A
Fast transients (Burst)	EN 61000-4-4	AC Input lines DC Output lines IO-Link Output	4 kV 4 kV 2 kV*	Criterion A Criterion A Criterion A
Surge voltage on AC input	EN 61000-4-5	Lx to Ly L to -PE	2 kV 4 kV	Criterion A Criterion A
Surge voltage on DC output	EN 61000-4-5	+ to - +/- to PE	1 kV 1 kV	Criterion A Criterion A
Surge voltage on IO-Link	EN 61000-4-5	IO-Link to PE	1 kV*	Criterion A
Conducted immunity	EN 61000-4-6	0.15 – 80 MHz	20 V*	Criterion A
Voltage dips	EN 61000-4-11	0 V 40 % of V _{nom} 70 % of V _{nom}	1 cycle 200 ms 500 ms	Criterion A Criterion A Criterion A
Voltage interruptions	EN 61000-4-11	0 V	5000 ms	Criterion C
Powerful transients	VDE 0160	Over entire load range	1550 V, 1.3 ms	Criterion A

Performance criterions:

A: The device shows normal operation behavior within the defined limits.

C: Temporary loss of function is possible. The device may shut-down and restarts by itself. No damage or hazards for the device will occur.

^{*} For IO Link certification immunity test levels according EN 61326-1:2013-01 have been tested





EMC Emission

Harmonics

Conducted emission AC input lines Conducted emission DC output lines Conducted emission IO-Link output Radiated emission EN 55032 , FCC Part 15 Class B

EN 55032 / EN 55011 Class B

FCC Part 15

EN 61000-3-2 Pass for Class A equipment

Voltage fluctuations, flicker EN 61000-3-3 Pass tested with constant current loads,

non pulsing

This device complies with FCC Part 15 rules.

Operation is subjected to following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Switching Frequencies


0 kHz to 135 kHz 🔠 Ir	nput voltage and output load dependent
0 kHz to 140 kHz C	Output load dependent
4 kHz to 66 kHz C	Output load dependent
8 Mhz and 32 MHz F	ixed frequency
(0 kHz to 140 kHz (4 kHz to 66 kHz (





16. Environment

Operational temperature	-25 °C to +70 °C (-13 °F to 158 °F)	Operational temperature is the same as the ambient or surrounding temperature and is defined as the air temperature 2cm below the unit.	
Storage temperature	-40 °C to +85 °C (-40 °F to 185 °F)	For storage and transportation	
Output derating	10 W/°C 33 W/1000 m or 5 °C/1000 m	Between +45 °C and +70 °C (113 °F to 140 °F) For altitudes >2000 m (6560 ft), see Fig. 16-2: Output power vs. : Output power vs. ambient temp. olled. The user has to take care to stay below the	
	derated current limits in order not to		
Humidity	5 to 95 % r.h.	According to IEC 60068-2-30	
Atmospheric pressure	54-110k Pa	see Fig. 16-2: Output power vs. for details	
Altitude	Up to 5000 m (16 400 ft)	see Fig. 16-2: Output power vs. for details	
Over-voltage category	III	According to IEC 60664-1	
	II	For TN, TT mains systems with earthed neutral and IT star mains systems with insulation monitoring for altitudes up to 2000 m According to IEC 60664-1 For TN, TT mains systems with earthed neutral and IT star mains systems with insulation monitoring for altitudes between 2000 m and 5000 m According to IEC 60664-1 For TN, TT, IT Delta mains systems or IT star mains systems without insulation monitoring for altitudes up to 2000 m	
Degree of pollution	3	According to IEC 62477-1, not conductive	
Vibration sinusoidal	2-17.8 Hz: ±1.6 mm; 17.8-500 Hz: 2 g 2 hours / axis	According to IEC 60068-2-6	
Shock	30 g 6 ms, 20 g 11 ms 3 bumps / direction, 18 bumps in total Shock and vibration is tested in comb a height of 15 mm and a thickness of	According to IEC 60068-2-27 ination with DIN-Rails according to EN 60715 with f 1.3 mm and standard orientation.	
LABS compatibility	Yes		
Audible noise	Some audible noise may be emitted from the power supply during no load, overload		



or short circuit.

Fig. 16-1: Output power vs. ambient temp.




Fig. 16-2: Output power vs. altitude





17. Safety and Protection Features

Isolation resistance	min.	500 MOhm	At delivered condition between input and output, measured with 500 Vdc
	min.	500 MOhm	At delivered condition between input and PE, measured with 500 Vdc
PE resistance Input/Output separation	max.	0.1 Ohm PELV	Resistance between PE terminal and the housing IEC/EN/UL 61010-2-201, IEC/EN 62368-1, IEC/EN 60950-1
Output over-voltage protection	typ. max.	31.8 Vdc 32.5 Vdc	
			ct, a redundant circuit limits the maximum output voltage. Id automatically attempts to restart
Class of protection			According to IEC 61140 A PE (Protective Earth) connection is required
Ingress protection		IP65 and IP67	According to EN/IEC 60529
Over-temperature protection		Included	Output shut down with automatic restart. Temperature sensors are installed on critical components inside the unit and turns the unit off in safety critical situations, which can happen e.g. when ambient temperature is too high, ventilation is obstructed or the de-rating requirements are not followed. There is no correlation between the operating temperature and turn-off temperature since this is dependent on input voltage, load and installation methods.
Input transient protection		MOV (Metal Oxide Varistor)	For protection values, see chapter 23, EMC.
Internal input fuse		Included	Not user replaceable slow-blow high-breaking capacity fuse
Touch current (leakage current)	max.	0.45 / 1.5 mA	At 3x 480 Vac, 60 Hz, TN-,TT-mains / IT-mains Lower currents at lower voltages and frequencies.





18. Dielectric Strength

The negative terminal of the outputs is permanently connected to PE within the unit. The output is insulated from the input by a double or reinforced insulation.

Type and routine tests are conducted by the manufacturer. Field tests may be conducted in the field using the appropriate test equipment which applies the voltage with a slow ramp (2s up and 2s down). Connect all input-terminals before conducting the test. When testing, set the cut-off current settings to the value in the table below.




Fig. 18-1: Dielectric strength

		Α	D
Type test	60 s	2830 Vac	500 Vac
Routine test	5 s	2550 Vac	500 Vac
Field test	5 s	2000 Vac	500 Vac
Cut-off current se	tting	>10 mA	>10 mA





19. Approved, Fulfilled or Tested Standards

IEC 62368 CB Scheme Certificate

CB Report IEC 62368-1 - Audio/video, information and communication

technology equipment - Safety requirements

Output safety level: ES1

IEC 61010 CB Scheme Certificate

Safety ✓ IEC 61010-2-201 - Electrical Equipment for Measurement, Control and

Laboratory Use - Particular requirements for control equipment

IEC 60950 Manufacturers Declaration

CB Report IEC 60950-1 - General safety requirements for Information Technology

Equipment (ITE)

UL 61010 UL Certificate

Listed equipment for category NMTR - UL 61010-2-201 - Electrical equipment for measurement, control and laboratory use - Particular

requirements for control equipment Applicable for US and Canada

E-File: E198865

Semi F47 Test Repo

Voltage Sag Immunity for Semiconductor Processing Equipment Tested

for 400VAC L-L mains voltages, nominal output voltage and nominal

output load

VDMA 24364 Paint Wetting Impairment Substances Test (or LABS-Test)

Tested for Zone 2 and test class C1 according to VDMA 24364-C1-L/W for

solvents and water-based paints

20. Regulatory Product Compliance

EU Declaration of Conformity

 ϵ

VDMA 24364-C1-L/W

Trade conformity assessment for Europe

The CE mark indicates conformance with the European

EMC directive

Low-voltage directive (LVD)

- RoHS directive

WEEE Directive



Manufacturer's Statement

EU-Directive on Waste Electrical and Electronic Equipment (WEEE) registered in Germany as business to business (B2B) products.

WEEE-Reg.-Nr. DE 55837529

REACH Regulation (EU)



Manufacturer's Statement

EU regulation regarding the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH) fulfilled.

China RoHS



Manufacturer's Statement

The device meets the Measures for Restriction of the Use of Hazardous Substances in Electrical & Electronic Products according the China-RoHS requirements.

The device is marked with EFUP symbol 25 years (Environmentally Friendly Use Period)

IEC/EN 61558-2-16 (Annex BB) Safety Isolating Transformer

Safety Isolating Transformers corresponding to Part 2-6 of the IEC/EN 61558






21. Accessories

21.1. DIN RAIL Mounting KIT: ZM.FPDRA-11


In addition to screw mounting FIEPOS can easily be attached to a DIN rail using the ZM.FPDRA-11 DIN rail mounting kit.



- DIN-Rail not included
- DIN-Fixture pre-assembled

21.2. Mounting Braket: ZM.FPMBA-11

In addition to screw mounting FIEPOS can easily be attached to a mounting bracket the ZM.FPMBA-11.







21.3. Connectors

FIEPOS features a large number of different connectors. Mating connectors can be ordered at PULS from stock in order to supply customers quickly during the design-in phase.

For a higher demand or other connector options go to HARTING-PULS-cabling.

Connector Name Harting HANQ4/2	PULS order code ZCF.hanq42	Harting order code 6104401263700	Connector Description Q4/2 Set AS female 2.5-6mm² 7-13mm
Harting HANQ4/2	ZCF.hanq42-1	6104401263800	Q4/2 Set AS female 2.5-6mm ² 14-17mm
Harting HANQ2/0	ZCM.hanq20	6104401263900	Q2/0 Set screw male 2.5-6mm ² 6-12mm
Harting HANQ4/0	ZCM.hanq40	6104401265100	Q4/0 Set crimp 2,5mm ² IP67
Harting HANQ5/0	ZCF.hanq50	6104401265000	Q5/0 Set QuickLock female 0.5-2.5mm² 6-12mm
Harting M12-A	ZCF.m12a5p	21032722505	M12-A 5pin cut clamp female 0.34-0.5mm² / 6-8mm
Harting M12-A	ZCM.m12a5p	21032721505	M12-A 5pin cut clamp male 0.34-0.5mm² / 6-8mm
Harting M12-S	ZCF.m12s4p	6102201020400	M12-S 4pin screw female 2.5mm ² / 6-8mm
Harting M12-L	ZCM.m12l5p	21032961505	M12-L 5pin cut clamp male 0.75-1.5mm² / 5.8-13.5mm
Harting M12-T	ZCM.m12t4p	6102201021000	M12-T 4pin screw male 1.5mm ² / 8-10mm
Harting 7/8"	ZCM.78inch4p	6102201021100	7/8" 4pin screw male 1.5mm² / 6-8mm
Harting 7/8"	ZCF.78inch3p	6102201021200	7/8" 3pin screw female 1.5mm² / 6-8mm
Harting 7/8"	ZCM.78inch5p	21041162505	7/8" 5pin screw male 0.75-1.5mm² / 6.8-12.5mm





22. Related Products

The FIEPOS product family includes various devices with different technical parameters and features. The following page provides a general overview of the available solutions. Please also get in touch with your PULS contact person, for more detailed application advice and technical information.

FPT500.245-034-106:

Power Supply with two fused channels (2–12 A) on two output connectors and Output OK.



SHORT-FORM DATA

Input voltage 3AC 380-480 V $\pm 15 \%$ Output voltage DC 24 V Nominal

Adjustment range 24-28 Vdc Factory setting 24.5 V

Output power Continuous:

600 W Up to +45 °C ambient 500 W At +55 °C ambient 350 W At +70 °C ambient

Short-term, up to 5 s:

1000 W Below +55 °C ambient 700 W At +70 °C ambient Derate linearly between +55 °C to +70 °C

Number of outputs 2

Output current Settable per output; up to 12 A

Input connector M12-S Output connector M12-L

FPT500.245-053-113:

Power Supply with two fused channels (2–10 A) on two output connectors and Output OK.



SHORT-FORM DATA

Input voltage 3AC 380-480 V $\pm 15 \%$ Output voltage DC 24 V Nominal

Adjustment range 24-28 Vdc Factory setting 24.5 V

Output power Continuous:

600 W Up to +45 °C ambient 500W At +55 °C ambient 350W At +70 °C ambient

Short-term, up to 5s:

1000W Below +55 °C ambient 700W At +70 °C ambient Derate linearly between +55 °C to +70 °C

Number of outputs 2

Output current Settable per output; up to 10 A

Input connector 7/8" 4pin Multicoded

Output connector 7/8" 5pin





23. Application Notes

23.1. Repetitive Pulse Loading

Typically, a load current is not constant and varies over time. This power supply is designed to support loads with a higher short-term power demand (BonusPower). The short-term duration is hardware controlled by an output power manager and is available on a repeated basis. If the average load is higher than the sum of all output power, the output voltage will dip. To avoid this, the following rules must be followed:

- a) The power demand of the pulse must be below 200 of the nominal output power.
- b) The duration of the pulse power must be shorter than the allowed BonusPower time, see chapter 6
- c) The average power should be lower than the nominal output power.

The R.M.S. output current must be below the specified continuous output current. If the R.M.S. current is higher, the unit may respond with a thermal shut-down after a period of time.

23.2. External Input Protection

The device is designed, tested and approved for branch circuits up to 20 A (UL) and 32 A (IEC) without additional protection device. If an external fuse is utilized, do not use circuit breakers smaller than 6 A B- or C-Characteristic to avoid a nuisance trip.


23.3. Two Phases Operation

No external protection devices are required to protect against a phase-loss.

Continuous two phase operation is not recommended for this power class since the supplying 3-phase network could become unbalanced. However, if one phase fails, the unit may continue to operate if the load is below the power limit shown in Fig. 24-1.

Exceeding of these limits for an extended period may result in a thermal shutdown of the unit.

During power-on, some start-up attempts can occur until a permanent output power is available. EMC performance, hold-up time, losses, and output ripple differ from a three phase operation. Such use is not included in the approval according to UL61010 and IEC62368.






Fig. 23-1: Two phase power capability

23.4. Inductive and Capacitive Loads

The unit is designed to supply any kind of loads, including capacitive and inductive loads. If extreme large capacitors, such as EDLCs (electric double layer capacitors or "UltraCaps") with a capacitance larger than 20mF are connected to the output, the unit might charge the capacitor or the output might trip, chapter 6.






23.5. Back Feeding Loads

Loads such as decelerating motors and inductors can feed voltage back to the power supply. This feature is also called return voltage immunity or resistance against Back- E.M.F. (Electro Magnetic Force).

This power supply is resistant and does not show malfunctioning when a load feeds back voltage to the power supply. It does not matter whether the power supply is on or off.

23.6. Mounting Orientations

The device can be mounted in various mounting orientations. The listed lifetime and MTBF values from this datasheet apply only for the standard mounting orientation. The following curves give an indication for allowed output power in different mounting orientations for altitudes up to 2000 m (6560 ft).







24. IO-Link Data Types and Description

24.1. Cyclic Data

The first dataset is called process data and refers to data that is periodically sent to the IO-Link master. The data is updated and communicated every 2ms. All other data in the power supply itself is generated every 50ms and stored in the IO-Link registers. The higher cycle frequency enables operation with IO-Link masters and attached PLCs without configuration.

Process	Sub-index	Bit offset	Data type	Bit length	Data Format	Resolution	Allowed values
Actual Output total Current	1	88	uint16_t	16	Q8.8	2 ⁻⁸ A/bit	
Actual Output Voltage	2	72	uint16_t	16	Q8.8	2 ⁻⁸ A/bit	
E-Fuse Current CH1	3	56	uint16_t	16	Q8.8	2 ⁻⁸ A/bit	
E-Fuse Current CH2	4	40	uint16_t	16	Q8.8	2 ⁻⁸ A/bit	
E-Fuse Current CH3	5	24	uint16_t	16	Q8.8	2 ⁻⁸ A/bit	
E-Fuse CH1 state	11	16	bool	1	-	-	t O
E-Fuse CH2 state	12	17	bool	1	-	-	true = On false = Off
E-Fuse CH3 state	13	18	bool	1	-	-	18136 = 011
E-Fuse CH1 overload trip state	15	8	bool	1	-	-	
E-Fuse CH2 overload trip state	16	9	bool	1	-	-	true = tripped false = Ok
E-Fuse CH3 overload trip state	17	10	bool	1	-	-	idisc = Ok
E-Fuse CH1 short circuit state	19	0	bool	1	-	-	
E-Fuse CH2 short circuit state	20	1	bool	1	-	-	true = tripped false = Ok
E-Fuse CH3 short circuit state	21	2	bool	1	-	-	iaise – Ok





Octet Subindex Bit offset	0 1 119-112	1 1 111-104	2 2 103-96	3 2 95-88	4 3 87-80	5 3 79-72	6 4 71-64	7 4 63-56	8 5 55-48	9 5 47-40
Die Orisee	113 112	111 104	103 30		07 00	75 72	7104	05 50	33 40	47 40
				Octet 10						
Subindex	-	-	-	-	-	13	12	11		
Bit offset	23	22	21	20	19	18	17	16		
				Octet11						
Subindex	-	-	-	-	-	17	16	15		
Bit offset	15	14	13	12	11	10	9	8		
				Octet12						
Subindex	-	-	-	-	-	21	20	19		
Bit offset	7	6	5	4	3	2	1	0		





24.2. Acyclic data

The parameter values can be accessed to read out additional data (e.g. current output voltage, temperatures etc.), but in addition some of these values can also be written by the user to configure the power supply (e.g. output voltage and remote on/off).

Parameter	Para. Index	Sub- index	Data type	Bit offset	Data Format	Resolution	Default values	Read [R] Write [W]	Allowed values	Description
Output Voltage Setpoint	105	0	uint16	15-0	Q8.8	2 ⁻⁸ V/bit	6272 (24.5V)	R/W	61447168	Output Voltage Setpoint Minimum value is 24.0V Maximum value is 28.0V
Standby	101	0	bool				0	R/W	0 = PSU normal operation (default value) 1 = PSU standby	Dynamic, excluded from data storage
Configuration Setting	103	0	uint8	7-0			2	R/W	0 = human-machine interface only 1 = IO-Link only 2 = both (default value) 3 = none (button lock)	Dynamic
E-Fuse Channel on/off Chanel 1 Chanel 2 Chanel 3	106	0	bool array 8-bit Record				1	R/W	0 = off 1 = on	Dynamic Bit 37 not used Access via subindex 0 only
E-Fuse trip value all CH E-Fuse trip value CH1 E-Fuse trip value CH2 E-Fuse trip value CH3	108	0 1 2 3	uint16 array uint16 uint16 uint16	47-0 47-32 31-16 15-0	Q8.8 Q8.8 Q8.8 Q8.8	2 ⁻⁸ A/bit 2 ⁻⁸ A/bit 2 ⁻⁸ A/bit 2 ⁻⁸ A/bit	max max max max	R R R R	2562560 at 10A 2563072 at 12A 2562560 at 10A 2563072 at 12A 2562560 at 10A 2563072 at 12A 2562560 at 10A 2563072 at 12A	Dynamic Default is max. current available
E-Fuse Pre-alarm level all CHs E-Fuse Pre-alarm level CH1 E-Fuse Pre-alarm level CH2 E-Fuse Pre-alarm level CH3	109	0 1 2 3	uint8 array uint8 uint8 uint8	23-0 23-16 15-8 7-0	Q9.7 Q9.7 Q9.7 Q9.7	2 ⁻⁷ /bit 2 ⁻⁷ /bit 2 ⁻⁷ /bit 2 ⁻⁷ /bit	103 (80%) 103 (80%) 103 (80%) 103 (80%)	R/W R/W	13192 (10% -150%) 13192 (10% -150%) 13192 (10% -150%) 13192 (10% -150%)	Dynamic
PSU total output current Pre-alarm level	104	0	uint16	15-0	Q8.8	2 ⁻⁸ A/bit	5120 (20A)) R/W	25625600 (1A-100A)	Dynamic
EEPROM Status	64	0	uint8	7-0				R	0 = ok 1 = recoverable error detected 2 = unrecoverable error	Dynamic





Parameter	Para. Index	Sub- index	Bit offset	Data type	Bit length	Read [R] Write [W]	Description
PSU events	65			uint16	16	R	Dynamic
Output-OK		1	0	bool		R	bit 0Output Voltage >90% of adjusted output voltage
DC-Warning		2	1	bool		R	bit 1 Output voltage dips more than 10% below adjusted output voltage
Bonus Power		3	2	bool		R	bit 2 Output current is 5% more than maximum for more than 3s
Over Temperature CAP		4	3	bool		R	bit 3Temperature Capacitor is higher than 95°C
Over Temperature PSU		5	4	bool		R	bit 4 Temperature of PSU is higher than 95°C
Over Load		6	5	bool		R	bit 5 Load higher than allowed
High Voltage Input		7	6	bool		R	bit 6 Input to high
Low Voltage Input		8	7	bool		R	bit 7 Input to low
Power Supply down		9	8	bool		R	bit 8 No link from IO-Link Transceiver to Power Supply
Predictive Maintenance Power Supply	1	10	9	bool		R	bit 9 Operating hours exceed estimated lifetime
2 phase operation		11	10	bool		R	Bit 10 One leg of the 3-Phase-System is missing
PSU hardware failure		14	13	bool		R	bit 13PSU hardware failure

Octet 0										
Subindex	15	14	13	12	11	10	9	8		
Bit offset	-	-	14	-	-	11	10	9		
	Octet1									
Subindex	7	6	5	4	3	2	1	0		
Bit offset	8	7	6	5	4	3	2	1		





Parameter	Para. Index	Sub- index	Data type	Bit offset	Data Format	Resolution	Default values	Read [R] Write [W]	Allowed values	Description
Temperature secondary inside	69	0	int16	15-0	Q9.7	2 ⁻⁷ °C/bit		R	-512032640	Temperature secondary inside PSU -40 150°C
Max. temperature secondary inside	70	0	int16	15-0	Q9.7	2 ⁻⁷ °C/bit		R	-512032640	Maximum temperature secondary inside PSU -40 150°C
Temperature primary inside	71	0	int16	15-0	Q9.7	2 ⁻⁷ °C/bit		R	-512032640	Temperature primary inside -40 150°C
Max. temperature primary inside	72	0	int16	15-0	Q9.7	2 ⁻⁷ °C/bit		R	-512032640	Maximum temperature primary inside -40 150°C
AC Input Voltage RMS	78	0	uint16	15-0	Q12.4	2 ⁻⁴ V/bit		R	024000 (0-1500V)	Actual Input Voltage RMS (phase-phase)
Actual output voltage	79	0	uint16	15-0	Q8.8	2 ⁻⁸ V/bit		R	012544 (0-49V)	Actual average output voltage
Actual output current	81	0	uint16	15-0	Q8.8	2 ⁻⁸ V/bit		R	012800 (0-50V)	Actual average output current
E-Fuse current all CHs E-Fuse current CH1 E-Fuse current CH2 E-Fuse current CH3	84	0 1 2 3	Unit16 array uint16 uint16 uint16	47-0 47-32 31-16 16-0	Q8.8 Q8.8 Q8.8 Q8.8	2 ⁻⁸ A/bit 2 ⁻⁸ A/bit 2 ⁻⁸ A/bit 2 ⁻⁸ A/bit		R	012800 (0-50A) 012800 (0-50A) 012800 (0-50A) 012800 (0-50A)	Actual average E-Fuse current all CH Actual average E-Fuse current CH1 Actual average E-Fuse current CH2 Actual average E-Fuse current CH3
E-Fuse output status Channel 1 Channel 2 Channel 3	85	0	Array of bool 8-bit Record	0 1 2				R	0off 1on	Dynamic Bit 37 not used Access via subindex 0 only
E-Fuse trip status CH1 E-Fuse trip status CH2 E-Fuse trip status CH3	86	0	4-bit enum array	3-0 7-4 11-8				R	0 = No trip 1 = Over-load trip 2 = Short circuit trip 3 = Temperature trip 4 = Power budget trip 5 = Installation failure trip 6 = Sensor fault trip 7 = Fatal fault trip	Dynamic Bit 1215 not used Access via subindex 0 only
Stress level	66	0	uint8	7-0				R	0 "<=5%" 1 ">5%" 2 ">=25%" 3 ">=50%" 4 ">=75%"	current load





Parameter	Para. Index	Sub- index	Data type	Bit offset	Data Format	Resolution	Default values	Read [R] Write [W]	Allowed values	Description
Remaining Endurance LED coded	67	0	uint8	7-0				R	0 "<=10%" 1 ">10%" 2 ">=25%" 3 ">=50%" 4 ">=75%"	Dynamic
Remaining Endurance	68	0	uint8	7-0		%	99	R	1099	Remaining Endurance in percent Value range 10 to 99 %





Counter

Parameter	Para. Index	Sub- index	Data type	Bit offset	Data Format	Resolution	Default value	Read [R] Write [W]	Allowed values	Description
E-Fuse Number of Startups all CHs E-Fuse Number of Startups CH1 E-Fuse Number of Startups CH2 E-Fuse Number of Startups CH3	87	0 1 2 3	uint32 array uint32 uint32 uint32	95-0 95-64 63-32 31-0			0	R	0150000 0150000 0150000 0150000	Number of Startups all Channels Number of Startups Channel 1 Number of Startups Channel 2 Number of Startups Channel 3
E-Fuse Number of Overcurrents all CHs E-Fuse Number of Overcurrents CH1 E-Fuse Number of Overcurrents CH2 E-Fuse Number of Overcurrents CH3	88	0 1 2 3	uint16 array uint16 uint16 uint16	47-0 47-32 31-16 15-0			0	R		Number of Overcurrents all Channels Number of Overcurrents Channel 1 Number of Overcurrents Channel 2 Number of Overcurrents Channel 3
Operating time hours minutes	73	0	uint32 uint8	39-8 7-0		h min		R	059	Access via subindex 0 only Operating hours Operating minutes
Transient VDE-0160 Counter overall	74	0	uint32	31-0			0	R	0150000	Transient Counter overall
Transient VDE-0160 Counter last 2 minutes	75	0	uint32	31-0			0	R	0150000	Transient Counter last 2 minutes
Turn-on Counter	82	0	uint32	31-0				R	0150000	Turn-on Counter of the PSU
Uptime since last turn-on hours minutes	83	0	uint32 uint8	39-8 7-0		h min		R	059	Access via subindex 0 only Uptime since last turn-on - hours Uptime since last turn-on - minutes

41 / 42





Device Status

Parameter	Para. Index	Sub- index	Data type	Bit offset	Read [R] Write [W]	Allowed values	Description
Device Status	36	0	uint8	7-0	R	0Device is operating properly1Maintenance-Required2Out-of-Specification3Functional-Check4Failure	0Device is operating properly1Maintenance-Required2Out-of-Specification3Functional-Check4Failure
Detailed Device Status Item [1] Item [2] Item [3] Item [4] Item [5]	37	0 1 2 3 4 5	3-OctetString array[5] 3-OctetString 3-OctetString 3-OctetString 3-OctetString 3-OctetString	119-96 95-72 71-48 47-24 23-0	R		Shows up to 5 pending events (3 octets per subindex) Octet 1EventQualifier Octet 2, 3EventCode





24.3. Events

This information is triggered by certain situations and will result in an event notification to the IO-Link master. Typical events are notification in case of ideal (e.g. DC-OK) and non-ideal situations (e.g. ambient temperature too hot, high input voltage etc.).

Events Parameter error – Check data sheet and values	Event-code 0x6320	Event-type Error	Description
Device temperature over-run – Clear source of heat	0x4210	Warning	
Events. DC-Warning	0x1800	Warning	Output voltage dips more than 10% below adjusted output voltage
Events. Bonus Power	0x1801	Notification	Output current is 5% more than maximum for more than 3s
Events. Over Load	0x1802	Warning	Load higher than allowed
Events. High Voltage Input	0x1803	Warning	Input to high
Events. Low Voltage Input	0x1804	Warning	Input to low
Events. Power Supply down	0x1805	Warning	No link from IO-Link Transceiver to Power Supply
Events. Predictive Maintenance Power Supply	0x1806	Warning	The estimated remaining lifetime has reached 10%. Performance of PSU might be limited due to aging effects of components.
Events. Two Phase Supply	0x1807	Warning	One leg of the 3-Phase-System is missing
Events. PSU setting changed via HMI	0x1809	Notification	A PSU setting was changed via man-machine interface.
Events. PSU hardware failure	0x1825	Warning	Critical PSU hardware failure detected. PSU shut down.
Events. PSU output current pre-alarm	0x1830	Warning	Total PSU output current exceeds pre-alarm limit
Events. E-Fuse CH1 Tripped	0x1840	Warning	E-Fuse Ch1 tripped due to overcurrent
Events. E-Fuse CH2 Tripped	0x1841	Warning	E-Fuse Ch2 tripped due to overcurrent
Events. E-Fuse CH3 Tripped	0x1842	Warning	E-Fuse Ch3 tripped due to overcurrent
Events. Output current pre-alarm CH1	0x1850	Notification	Output current on E-Fuse Ch1 exceeds pre-alarm limit
Events. Output current pre-alarm CH2	0x1851	Notification	Output current on E-Fuse Ch2 exceeds pre-alarm limit
Events. Output current pre-alarm CH3	0x1852	Notification	Output current on E-Fuse Ch3 exceeds pre-alarm limit